



Chafers & Tureen



**EXTRA
CHARGE IF
RETURNED
DIRTY**

OPERATING INSTRUCTIONS:

Chafing Dish and Tureen (Using Canned Type Heat)

1. Do not use anything but CANNED TYPE FUEL in the burner.
2. NEVER light the burner unit before putting liquid into the water pan or tureen. Low flame is sufficient to maintain proper heat.
3. Do not put unit on a hot stove or an open flame.
4. Chafing dish water pans should be filled with hot water. Deeper food pans require less water. Check water pan when in use to insure sufficient water is contained at all times.
5. DO NOT USE WITHOUT WATER. DO NOT OVERFILL WATER PAN.
6. Do not use food pans for cooking or baking.

Use of Canned Heat

Open canned fuel container into the heat cup. Light fuel and adjust lid of heat cup at approximately 1/2 open. One can of heat should last approximately 5 hours.

Cleaning Instructions

Before returning chafing dish, scrape and wash food pans. Wash chafing dish and tureen in lukewarm water and mild detergent. NEVER USE HARSH ABRASIVES.

REMEMBER, you are renting this equipment. Be sure you are aware of the terms of your rental contract. Always return your chafing dish or tureen clean to avoid additional cleaning charges.



Chafers & Tureen



**EXTRA
CHARGE IF
RETURNED
DIRTY**

OPERATING INSTRUCTIONS:

Chafing Dish and Tureen (Using Canned Type Heat)

7. Do not use anything but CANNED TYPE FUEL in the burner.
8. NEVER light the burner unit before putting liquid into the water pan or tureen. Low flame is sufficient to maintain proper heat.
9. Do not put unit on a hot stove or an open flame.
10. Chafing dish water pans should be filled with hot water. Deeper food pans require less water. Check water pan when in use to insure sufficient water is contained at all times.
11. DO NOT USE WITHOUT WATER. DO NOT OVERFILL WATER PAN.
12. Do not use food pans for cooking or baking.

Use of Canned Heat

Open canned fuel container into the heat cup. Light fuel and adjust lid of heat cup at approximately 1/2 open. One can of heat should last approximately 5 hours.

Cleaning Instructions

Before returning chafing dish, scrape and wash food pans. Wash chafing dish and tureen in lukewarm water and mild detergent. NEVER USE HARSH ABRASIVES.

REMEMBER, you are renting this equipment. Be sure you are aware of the terms of your rental contract. Always return your chafing dish or tureen clean to avoid additional cleaning charges.